



AQUA CLEAR COAT

HOW TO USE:

Before coating, the floor must be clean and free of oil, dirt, and chemical residue. Acid stained floors must be rinsed thoroughly to be free of any residues, and dry before sealing.

To the clean dry floor apply Aqua Clear Coat by roller only. Apply three thin coats at the rate of 800 - 1000 sq.ft. per gallon for each coat.

Allow each coat to dry for one hour and apply the next coat. Allow to dry for 24 hours before allowing traffic.

Do not over apply. Make sure concrete is cured and totally dry before applying. Do not allow to puddle. Any lines, high areas or marks created by roller need to be rolled back out to level out while still wet.

CLEAN UP:

Wash brushes and equipment with warm water and soap. Rinse clean.

PRECAUTIONARY STATEMENT:

Do not handle until all safety precautions have been read and understood. Wash skin thoroughly after handling. Do not eat, drink or smoke when using this product. Wear protective gloves/protective clothing/eye protection/face protection. Dispose of contents/container according to local, state and federal regulations.

FIRST AID:

EYES: Flush with water for 15 minutes, lifting both eyelids. If irritation persists, Get Medical Help.

INHALATION: Remove to fresh air immediately. If breathing difficulties continue, Get Medical Help.

INGESTION: Do not induce vomiting. Rinse mouth with water, and drink two glasses of water. Get Immediate Medical Help.

SKIN: Wash with soap and water. Remove contaminated clothing and launder before reuse.

IN CASE OF FIRE:

This product is not flammable.

FOR PROFESSIONAL USE ONLY

FOR EMERGENCY HELP

24 Hours a Day contact:

INFOTRAC at 1-800-535-5053

