PermaPro

GLU-GONE

HOW TO USE:

- 1. Apply Glu Gone full strength by spray or pour on and spread with a soft broom to thoroughly cover and penetrate the adhesive layer.
- 2. Allow the Glu Gone to soak for 25-45 minutes or until adhesive is easily scraped up.
- 3. Scrape off adhesive and flush off any residue with water. Remove material according to local, state and federal regulations.

Note: A small test area is recommended.

PRECAUTIONARY STATEMENT:

Avoid breathing dust/fumes/gas/mist/vapors/spray. Wash hands thoroughly after handling. Do not eat, drink or smoke when using this product. Wear protective gloves/protective clothing/eye protection/face protection. Take off contaminated clothing and wash before reuse. Store in a well-ventilated place. Keep container tightly closed. Dispose of contents/container according to local, state and federal regulations. Do not use, spill, or store in a way that will allow product or rinsate to enter streams, lakes or water ways where fish or marine life may be adversely affected. Use caution around plants and grass areas as this product could harm them.

FIRST AID:

IF INGESTED: Drink two glasses of water. Do not induce vomiting. Get Immediate Medical Help. IF IN EYES: Flush thoroughly with water for 15 minutes, lifting both eyelids. If irritation persists, Get Medical Help. IF ON SKIN: Rinse off thoroughly with soap and water. Wash contaminated clothing before reuse. EXCESSIVE INHALATION: Remove to fresh air. If breathing is difficult administer oxygen. Get Medical Help.

IN CASE OF FIRE:

This product is non-flammable.

FOR PROFESSIONAL USE ONLY

FOR EMERGENCY HELP 24 Hours a Day contact: INFOTRAC at 1-800-535-5053

